

Title	基本回線	Date		Place	セカンドクラッチ
-------	------	------	--	-------	----------

Channel Input

Ch	Input	Mic	Stand	Multi	Insert	Ch	Input	Mic	Stand	Multi	Insert
1	Bass L	J48mk2		32	17	17	Top L	C-451E	210	32	1
2	M	SM-58	259	"	18	18	" R	"	210	"	2
3	GTR	1 SM-57	"	"	19	19				"	3
4	"	2 e906	"	"	20	20	F.Tom	E904		"	4
5	"	3 SM-57	"	"	21	21	T.Tom 1	"		"	5
6	"	4 e906	"	"	22	22	" 2	"		"	6
7	KEY	1 DI-1		"	23	23	Hihats	C-451E	259	"	7
8	"	2 "		"	24	24	Snare Top	SM-57	"	"	8
9				"	25	25	" Btm	"	Clamp	"	9
10				"	26	26	Kick 1	Beta91		"	10
11				"	27	27	" 2	Beta52	259	"	11
12	SR Cho	SM-58	210	"	28	28				"	12
13	SL Cho	"	"	"	29	29				"	13
14	Center	SM-58	201	"	30	30				"	14
15	FB			"	31	31				"	15
16	SPARE			"	32	32	Drun Chorus	B58/OM3	210	"	16

OMNI out

Ch	name	MTX	AUX	Insert	Amp	SP	Co
1	Center1		MIX1	Rack2A	QSCGX5	FM1502	2
2	Ext1		MIX2	Rack2B	QSCGX5		
3	SR		MIX3	Rack3A	QSCGX5	FM1502	1
4	SL		MIX4	Rack3B	QSCGX5	FM1502	1
5	Drum		MIX5	Rack4A	QSCGX5	FM1502	1
6	Ext 2		MIX6	Rack4B	QSCGX5	FM1502	1
7							
8							
9							
10							
11	REC L	MTX5					
12	REC R	MTX6					
13	main L	MTX1		rack1A	Dr260	TMS4/728	
14	main R	MTX2		rack1B	amp*2	TMS4/728	
15	VTR L	MTX7					
16	VTR R	MTX8					

STEREO Input

Ch	Input	Mic	Stand	Multi	Insert
1	REV1	Rack5			
2	REV2	Rack6			
3	REV3	Rack7			
4	DDL	Rack8			

Channel Input

Ch	Input	Mic	Stand	Multi	Insert	Ch	Input	Mic	Stand	Multi	Insert
33						41					
34						42					
35						43	i-pod nano L				Safe
36						44	R				"
37						45	CD1 L	CD-500			"
38						46	R				"
39						47	CD2 L	CD-01U			"
40	Talk Back	SM-58S			safe	48	R				"

お問い合わせ

TEL: 082-249-7363

MAIL: info@ento-ebisu.com

機材リスト 2021.11月現在			
MIXER	YAMAHA M7CL-48 Slot1Analog 8in 8out Card	Main Input Multi Canare 32ch(Drヨコ32ch 後番シリーズ上下) Sub Multi Canare 8ch (PA-ドラムヨコ)	
Main SP	JBL SRX835P Powered *P.AMP AMCRON Class D JBL SRX728 (片側2/1)	Mics	SHURE SM-58 *5 SHURE SM-57 *4
Main C/D	dbx Driverack 260		DI
Main Amp	AMCRON XT14002(SRX728 Sub)	SHURE Beta 52 *1 SHURE Beta91A*1 SHURE Beta 57A *2	Countryman TYPE85*2(2番Hot) Boss DI-1*4 Radial J-48m12*1
FB Amp	AMCRON K2		
FB SP	Electro-Voice FM-1202 *5 Electro-Voice FM-1502(ER) *1	AKG C-451E*3 AKG C-391B *2	STAND
EXT	KLKARKTEKNIK DN360*1	ゼンハイザー e904 *5(Tom用) ゼンハイザー e906*2(E.Gtr用) old e904*1 AVDIX i5 *2 old e604*2 EV N/D 868 *1	Deck
			CD TASCAM CD-500 *2 REG CD-R TASCAM CD^RW900